Tanaka^{*}


Parts Catalog

Chain Saw

Model: ECS-290


Units Prior To Serial No. J 138950

FIG.1 ENGINE




	HER PARTIER	PARTIANE	SERIN NER REMARKS
1-001 1-001 1-002 1-002 1-006 1-007	157-04200-900 157-11666-900 018-00546-200	SPARK PLUG CAP ASS'Y SPARK PLUG CAP ASS'Y SPARK PLUG CJ8 SPARK PLUG CJ8 CYLINDER	1 P F131000 1 P F131001- 1 -F131000 1 P F131001-
1-008 1-009 1-010 1-011 1-012 1-013	041-01700-200 031-01700-200 037-01700-200	CYLINDER GASKET PISTON RING PISTON	4 1 2 1 1 2
1-016 1-016 1-017 1-018 1-019 1-019	046-01700-801 999-62091-325 068-10100-200 071-02007-200	CRANK SHAFT COMP. CRANK SHAFT COMP. NEEDLE BEARING F-910 WOOD-RUFF KEY 3X13X4.5 CRANK SHAFT SHIM 0.05 CRANK SHAFT SHIM 0.10	1 R -F131000 F131001-
1-019 1-019 1-021 1-022 1-023 1-024	071-02007-230 066-00000-200 992-10070-012 992-01070-011		V V I I I I I I I I I I I I I I I I I I
1-025 1-025 1-026 1-027 1-028 1-031		STEP BOLT STARTER PAVL STARTER PAVL SPRING SPECIAL WASHER	2 P J075960 2 P J075961- 2 2 2 2
1-032 1-033 1-034 1-035 1-036 1-037	205-01700-200	SMALL WASHER 4 TAB IGNITION COIL COMP. SCREW 5X25	2 2 1 1 4 4
1-041 1-042 1-043 1-044 1-045 1-046	999-66122-200 090-01700-200 999-61620-200 999-66152-500	CRANK CASE ASS'Y OIL SEAL 12227 CRANK CASE GASKET BALL BEARING #6202, 35MM/OD OIL SEAL 15257 NEEDLE ROLLER 2.5X9.8	
1-051 1-052 1-053 1-054 1-055 1-056	562-04060-200 031-32710-210 629-11600-900	TANK INNER CAP ASS'Y HOLDER PLATE B	
1-057 1-058 1-059 1-060,1 1-060	992-01050-011 992-10050-012 990-11050-161 994-15050-165	S. WASHER 5	2 H 2 H 2 H 2 2 H 2 2
1-064 1-064 1-065 1-066 1-071	243-32710-201 873-32710-800 203-10000-200 162-01300-900	DANPER REAR STAY DANPER REAR STAY HOLDER PLATE A COMP. PRIMARY CORD GROMMET STOP SWITCH ASS'Y STOP SWITCH ASS'Y	1
1-072 1-073 1-074		SWITCH NAME PLATE EARTH CORD COMP. COLLAR	

FIG.2 MUFFLER & CLEANER




	NER		ax ⁵
REF	NER PARTIER	PARWAME	SERIANDER REMARKS
2-001 2-002 2-003 2-004 2-005 2-006	051-32710-200 999-67003-000	CLEARER ELEMENT COMP. SCREW 5X40	
2-007 2-008 2-009 2-011 2-012 2-012	708-32350-200 700-32710-200 402-01700-200	CARBURETOR GASKET HEX. HOLE BOLT 5X25	1 2 1 1 2 R -F109350 2 N
2-012 2-013 2-014 2-015 2-015 2-016	992-10050-012 992-00050-011 404-01700-800	SMALL WASHER 5 CARBURETOR INSULATOR COMP. CARBURETOR INSULATOR COMP.	2 F109351- 2 I -F109350 1 F109351-
2-017 2-018 2-019 2-020 2-021 2-026	992-10030-012 990-11030-121 409-01700-200	SCREW 3X12 CARBURETOR INSULATOR RUBBER INLET MANIFOLD GASKET	
2-027 2-028 2-028 2-029 2-029 2-030	705-01710-900 717-01700-800 717-01712-800	WASHER 5 MUFFLER ASS'Y MUFFLER ASS'Y MUFFLER BODY B COMP. MUFFLER BODY B COMP. MUFFLER FITTING METAL	2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
2-031 2-031 2-033 2-036 2-037 2-038	732-01710-200 737-01700-200 993-41040-251 992-10040-012		1 F131500 F131501-
2-039 2-040		CLEANER COVER B CLEANER COVER C	

FIG.3 OIL FILTER & PUMP FILTER




	NER		/// ax5
REF	NER PARNER	PARMANE	SERIN WER REMARKS
3-001 3-002 3-003 3-004 3-004 3-005	505-32710-200 680-04019-210 992-01050-011 487-32712-200 487-32712-201	CLIP 7 VASHER 5 OIL FILTER	1 R -F109350 1 F109351-
3-006 3-007 3-011 3-012 3-013 3-014	442-25016-801 992-20100-010 991-11100-011	THROTTLE GUIDE PRIMING PUMP COMP. INNER TOOTHED WASHER 10	1 1 1 1 1 1 1 1 1 R -G038400
3-014 3-016 3-017 3-021 3-021 3-022	678-01700-200 675-11600-900 700-02004-150 700-02504-150	FUEL PIPE 2.5X4X105 RUBBER PIPE PUMP FILTER BODY ASS'Y FUEL PIPE 2X4X150 FUEL PIPE 2.5X4X150 RETURN GROMMET	G038401- R -G038400 G038401-
3-026 3-027 3-027 3-027 3-028 3-029 3-030	999-67018-000 520-32710-200 520-32710-201 190-32710-200 707-32710-200 704-32710-800	OIL TANK CAP OIL TANK CAP ADJUSTER CAP	1
3-031 3-032 3-033 3-033	191-32710-200 999-67020-000 628-32710-200	GRONNET	1

FIG.4 RECOIL STARTER




REF	NER PARNER		SERIANER REMARKS
4-000 4-000 4-001 4-002 4-003 4-004	756-01700-901 990-15050-126 786-01700-200	RECOIL STARTER ASS'Y RECOIL STARTER ASS'Y SCREW 5X12 RECOIL STARTER WASHER STARTER ROPE REEL	1
4-004 4-005,1 4-005 4-006 4-007 4-008	778-01700-901 779-01250-200	RECOIL SPRING CASE RECOIL SPRING CASE ASS'Y RECOIL SPRING STARTER HANDLE	1 R F131001- -F131000 1 F131001- 1 D F131001-
4-009 4-009 4-010	112-01700-801	FAN CASE COMP. FAN CASE COMP. SCREW 4X18/PS	1 I -F131000 F131001-


FIG.5 CARBURETOR



	<u>a</u> /		/// /5
REF	MER PARTIER	PARMANE	SET SERVENDER REMARKS
5-000 5-000 5-001 5-002 5-003 5-004	455-25027-900 455-25027-901 548-25016-200 476-25016-200 454-25027-800	CARBURETOR ASS'Y CARBURETOR ASS'Y	1 R -F109350 F109351-
5-005 5-006 5-007 5-008 5-009 5-009	475-25016-200 546-25001-200 605-25001-200 473-25001-200 477-25007-200 477-25013-200	VALVE HINGE VALVE SPRING	1 1 1 1 1 R -F109350 F109351-
5-010 5-011 5-012 5-013 5-014 5-014	491-25027-200 489-25007-200 488-25027-200	SHUTTER SCREW THROTTLE LEVER	1 2 1 1 1 1 R -F109350 F109351-
5-015 5-016 5-017 5-018 5-019 5-020	461-25027-200 485-25003-200 460-25027-200 486-25015-200	HIGH/LOW ADJUST SPRING LOW ADJUST SCREW HIGH ADJUST SPRING HIGH ADJUST SCREW THROTTLE SPRING THROTTLE SHAFT COMP.	
5-021 5-022 5-023 5-024 5-024 5-025	577-25007-200 575-25010-200 575-25028-200	PUMP DIAPHRAGN PUMP GASKET PUMP BODY	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
5-026 5-027	462-25016-200 514-25001-200	IDLE ADJUST SCREW	


FIG.6 OIL PUMP & SIDE CASE






, et	HER PARTIER	PARHAME	SERIA NER REMARKS
6-002 6-003, 1 6-003 6-003 6-004 6-005	121-32530-200 040-32710-800 040-32710-810 040-32710-811 287-01700-800	CHAIN BAR CLAMP NUT SIDE CASE COMP. SIDE CASE COMP. SIDE CASE COMP.	2 1 R -F131000 1 R -G038400 1 G038401-
5-006 6-007 6-008 6-009 6-010 6-011	358-04050-201 990-11040-121 992-10040-012 992-00040-011	CLUTCH HOUSING 3/8" CLUTCH WASHER SCREW 4X12 S.WASHER 4 SMALL WASHER 4 OIL PUMP COVER COMP.	1 1 4 4 4 1
6-012 6-013 6-014 6-016 6-016 6-017	488-32710-200 488-32710-210		1 1 1 1 1 1 1 1 1 1
6-017 6-018 6-019,1 6-019 6-020 6-021	999-67007-000 085-32710-200 088-32710-910	PUMP GEAR OIL PUMP CASE SET OIL PUMP CASE	1 N F131001- -F131000 1 N F131001- 1 D F131001-
6-022 6-023 6-024 6-025 6-031 6-032	348-01700-200 992-74004-143 993-41040-101 466-32710-200	CLUTCH SPRING CLUTCH PLATE A RIVET 4X14 SCREW 4X10 PLATE	1 2 2 2 1 1 1 1
6-033 6-034 6-036 6-037 6-038 6-039	101-32530-200 990-11050-121 992-10050-012 700-07105-020	S. WASHER 5	

FIG.7 HANDLE




	28		/// 15
REF	HER PARTIER	PARTIAME	SERIA NER REMARKS
7-001 7-002 7-003 7-004 7-005 7-006	990-11040-351 992-10040-012 992-01040-011	SCREV 4X35 S.VASHER 4 VASHER 4 FRONT HAND GUARD COMP. U-NUT 4	
7-007 7-008 7-009 7-009 7-010 7-010	275-32710-200	SMALL WASHER 5 DAMPER COLLAR A DAMPER COLLAR A DAMPER A	1 1 1 I -J075960 1 J075961- -J075960 2 J075961-
7-011 7-016 7-017 7-018 7-020 7-026	725-32600-202	REAR HANDLE B COMP. PUSH PIN CAP STOPPER SPRING PUSH PIN	2 N J075961-
7-027 7-028 7-031 7-032 7-033 7-034	061-32710-200 991-01040-011 991-01050-011 010-32710-200		1 1 2 1 1 1
7-035 7-036 7-037 7-038 7-039 7-041	992-10050-012 990-11050-401 992-00040-011 992-10040-012 990-11040-181 209-32710-200	SCREW 5X40 SMALL WASHER 4 S.WASHER 4 SCREW 4X18	1 1 3 3 3 1
7-042 7-042 7-043 7-043 7-044 7-045	276-32710-201	DAMPER B DAMPER COLLAR B DAMPER COLLAR B SMALL WASHER 5	1 I -J075960 1 J075961- 1 I -J075960 1 J075961-
7-046	990-11050-301	SCREW 5X30	
	1		
:			


FIG.8 TOOLS



REF	NER PARNER	PARTIAME	SERVANER REMARKS
8-001 8-002 8-003 8-005 8-005	862-20000-200 936-20000-900 943-32710-200	COMBI. BOX SPANNER 10X19 PLUS DRIVER 4 FILE ASS'Y 5/32" CHAIN COVER 12" CHAIN COVER 12"	1

FIG.9 MARKS





REF. NBR PARTIER	PARTAME	SE FINANTER REMARKS
9-001,1 915-32710-200 STARTER MARK 9-001,2 915-32710-201 STARTER MARK 9-001 950-32710-200 PROFORCE MARK 9-002,1 906-32710-200 NAME PLATE 9-002 906-01700-200 NAME PLATE 9-003 907-32750-200 CAUTION MARK	A	1 R -G038400 1 -J075960 1 N J075961- 1 -J075960 1 N J075961-